

IBM Personal System/2 Color Display 8514


Parts Supplement for PC and XT

Assembly 1: IBM Personal System/2 Color Display 8514



Asm - Index	Part Number	Units	Description
1 - 1		1	IBM Personal System/2 Color Display 8514 Assembly
- 1	75X5901		• 110/120 Volt
- 1	75X5902		• 220/240 Volt (Northern Hemisphere)
- 1	75X5903		• 220/240 Volt (Southern Hemisphere)
- 2	75X5907	1	Tilt/Swivel Stand
- 3	68X3071	1	Power Cord (US only)
			See Power Cord Parts List for other countries.

Assembly 2: Internal FRUs




Asm – Index	Part Number	Units	Description
2-1	75X5908	R	CRT/Yoke Assembly (Northern Hemisphere)
—	75X5909	R	CRT/Yoke Assembly (Southern Hemisphere)
—2	75X5910	R	Power Supply Assembly (110/120 Volt)
—	75X5911	R	Power Supply Assembly (220/240 Volt)
—3	75X5912	R	Analog and Video Card Assembly
—4	75X5914	R	Cover
—5	75X5915	R	Bezel
—6	75X5916	R	Brightness/Contrast Control Assembly
—7	75X5917	R	LED Assembly
—8	75X5918	R	Signal Cable Assembly
—9	75X5919	R	Degauss Coil Assembly
—10	75X5928	R	Metal Cover Kit
—	75X5921		Kit, Miscellaneous Hardware
—	75X5932	AR	Package Container
—	75X5945		110/120 Volt Monitor
—	75X5946		220/240 Volt Monitor (Northern Hemisphere)
—	75X5947		220/240 Volt Monitor (Southern Hemisphere)
—	75X8288	AR	Shipping Material Includes Box, Cushions, Poly Bag, and Dryer)

IBM Personal System/2 Color Display 8514


Parts Supplement for XT Model 286

Assembly 1: IBM Personal System/2 Color Display 8514



Asm – Index	Part Number	Units	Description
1 – 1		1	IBM Personal System/2 Color Display 8514 Assembly
– 1	75X5901		• 110/120 Volt
– 1	75X5902		• 220/240 Volt (Northern Hemisphere)
– 1	75X5903		• 220/240 Volt (Southern Hemisphere)
– 2	75X5907	1	Tilt/Swivel Stand
– 3	68X3071	1	Power Cord (US only)
			See Power Cord Parts List for other countries.

Assembly 2: Internal FRUs




Asm – Index	Part Number	Units	Description
2 – 1	75X5908	R	CRT/Yoke Assembly (Northern Hemisphere)
–	75X5909	R	CRT/Yoke Assembly (Southern Hemisphere)
– 2	75X5910	R	Power Supply Assembly (110/120 Volt)
–	75X5911	R	Power Supply Assembly (220/240 Volt)
– 3	75X5912	R	Analog and Video Card Assembly
– 4	75X5914	R	Cover
– 5	75X5915	R	Bezel
– 6	75X5916	R	Brightness/Contrast Control Assembly
– 7	75X5917	R	LED Assembly
– 8	75X5918	R	Signal Cable Assembly
– 9	75X5919	R	Degauss Coil Assembly
– 10	75X5928	R	Metal Cover Kit
–	75X5921		Kit, Miscellaneous Hardware
–	75X5932	AR	Package Container
–	75X5945		110/120 Volt Monitor
–	75X5946		220/240 Volt Monitor (Northern Hemisphere)
–	75X5947		220/240 Volt Monitor (Southern Hemisphere)
–	75X8288	AR	Shipping Material Includes Box, Cushions, Poly Bag, and Dryer)

IBM Personal System/2 Color Display 8514


Parts Supplement for AT

Assembly 1: IBM Personal System/2 Color Display 8514



Asm – Index	Part Number	Units	Description
1 – 1		1	IBM Personal System/2 Color Display 8514 Assembly
– 1	75X5901		• 110/120 Volt
– 1	75X5902		• 220/240 Volt (Northern Hemisphere)
– 1	75X5903		• 220/240 Volt (Southern Hemisphere)
– 2	75X5907	1	Tilt/Swivel Stand
– 3	68X3071	1	Power Cord (US only)
			See Power Cord Parts List for other countries.

Assembly 2: Internal FRUs




Asm - Index	Part Number	Units	Description
2-1	75X5908	R	CRT/Yoke Assembly (Northern Hemisphere)
-	75X5909	R	CRT/Yoke Assembly (Southern Hemisphere)
-2	75X5910	R	Power Supply Assembly (110/120 Volt)
-	75X5911	R	Power Supply Assembly (220/240 Volt)
-3	75X5912	R	Analog and Video Card Assembly
-4	75X5914	R	Cover
-5	75X5915	R	Bezel
-6	75X5916	R	Brightness/Contrast Control Assembly
-7	75X5917	R	LED Assembly
-8	75X5918	R	Signal Cable Assembly
-9	75X5919	R	Degauss Coil Assembly
-10	75X5928	R	Metal Cover Kit
-	75X5921		Kit, Miscellaneous Hardware
-	75X5932	AR	Package Container
-	75X5945		110/120 Volt Monitor
-	75X5946		220/240 Volt Monitor (Northern Hemisphere)
-	75X5947		220/240 Volt Monitor (Southern Hemisphere)
-	75X8288	AR	Shipping Material Includes Box, Cushions, Poly Bag, and Dryer)

IBM Personal System/2 Color Display 8514


Parts Supplement for Type 8530

Assembly 1: IBM Personal System/2 Color Display 8514



Asm – Index	Part Number	Units	Description
1 – 1		1	IBM Personal System/2 Color Display 8514 Assembly
– 1	75X5901		• 110/120 Volt
– 1	75X5902		• 220/240 Volt (Northern Hemisphere)
– 1	75X5903		• 220/240 Volt (Southern Hemisphere)
– 2	75X5907	1	Tilt/Swivel Stand
– 3	68X3071	1	Power Cord (US only)
			See Power Cord Parts List for other countries.

Assembly 2: Internal FRUs



Asm – Index	Part Number	Units	Description
2 – 1	75X5908	R	CRT/Yoke Assembly (Northern Hemisphere)
–	75X5909	R	CRT/Yoke Assembly (Southern Hemisphere)
– 2	75X5910	R	Power Supply Assembly (110/120 Volt)
–	75X5911	R	Power Supply Assembly (220/240 Volt)
– 3	75X5912	R	Analog and Video Card Assembly
– 4	75X5914	R	Cover
– 5	75X5915	R	Bezel
– 6	75X5916	R	Brightness/Contrast Control Assembly
– 7	75X5917	R	LED Assembly
– 8	75X5918	R	Signal Cable Assembly
– 9	75X5919	R	Degauss Coil Assembly
– 10	75X5928	R	Metal Cover Kit
–	75X5921		Kit, Miscellaneous Hardware
–	75X5932	AR	Package Container
–	75X5945		110/120 Volt Monitor
–	75X5946		220/240 Volt Monitor (Northern Hemisphere)
–	75X5947		220/240 Volt Monitor (Southern Hemisphere)
–	75X8288	AR	Shipping Material Includes Box, Cushions, Poly Bag, and Dryer)